

## **TPO Calculation**

K236BN, Cody, WY; FID # 71807

TPO X System Efficiency X Antenna Gain = ERP

16 watts X 50% (Coax loss & cavity filters) X 1.25 = 10 watts